
Study of ion damage on EUV light source collector mirrors

**Hiroshi Komori, Georg Soumagne, Hiroyuki Kondo, Tamotsu Abe,
Takashi Suganuma, Hiroshi Someya, Hideo Hoshino, Akira Endo, Koichi Toyoda**

**Hiratsuka Research Center,
Extreme Ultraviolet Lithography System Development Association
(EUVA)**

**2nd International EUVL Symposium
1st October 2003, Antwerp, Belgium**

Main EUVL light source requirements (Throughput 100wfr/hr)

- EUV Power 115 W
- Long lifetime collector mirror

Lifetime limitations :



- 1) EUV exposure, heat load
- 2) Cleanliness
- 3) Fast ions

Development of collector mirror lifetime extension technology

- Characterize ions from laser produced plasma using time-of-flight method (TOF)
- Clarify the damage mechanism of collector mirror caused by ions
Xe ion exposure test by :
 - 1) ion gun
 - 2) laser produced plasma
- Ion mitigation technology development
Examine effective ion mitigation methods


Experimental set up for ion energy measurement

3



Liquid Xe Jet and plasma

Experimental set up for ion energy measurement




TOF measurement

-Xenon Ion Energy: **3 keV peak.**
3 keV mean


0.5 keV peak.
7 keV mean

Laser Energy=200mJ,
Pulse Duration=8ns (fwhm),
Intensity = 7.5×10^{11} W/cm²

150 ps (fwhm)
 4×10^{13} W/cm²



Electro-static energy analyzer TOF signal




$$Mv^2 / R_0 = eZE(R_0)$$


(Centrifugal force = Charge x Electric field strength)

$$E_{\text{kin}} / Z = Mv^2 / 2Z$$

$$= e R_0 E(R_0) / 2$$

$$= ke \Delta V [\text{eV}] \quad : k=2.254$$





Laser: 160mJ, 8ns,
 $E_{\text{kin}}/Z = 1\text{keV}$, $Z=2$;
avg 50 pulse



Xe isotopes

Mass Number Xe	Rel. Abundance (%)
124	0.1
126	0.1
128	1.9
129	26.4
130	4.1
131	21.2
132	26.9
134	10.4
136	8.9

TOF signal dependence on laser pulse duration

Laser energy: 100mJ



Pulse duration: 8 ns, Intensity: 3.8×10^{11} W/cm² 150 ps, 2×10^{13} W/cm²



TOF signal dependence on laser energy

Laser energy: 160mJ

Pulse duration: 8 ns, Intensity: 6×10^{11} W/cm² 150 ps, 3.2×10^{13} W/cm²



Time-of-flight (TOF) ion measurement combined with electro-static energy analyzer.

- Xe^{2+} is the main ion from plasma.
- Up to Xe^{6+} ions are observed with 8-ns laser.
- Higher charge state Xe ions are observed with 150-ps laser.


- Study of the influence of high-energy ions on Mo/Si multilayer mirrors

Xe ion exposure measurement with ion gun (5keV Max)

- Simplify the damage analysis
- Well defined ion energy

Exposure test by laser produced plasma

- Exposure test under real environment ex. EUV, Residual gas, Contamination
- Difference in charge state LPP Xe⁺-Xe⁶⁺



Sample

- 10 Mo/Si bilayer Si substrate mirror, $\lambda=13.5$ nm

Exposure conditions

- Ion energy 2 – 5 keV
- Ion dose 2.8 – 3.7 x 10¹⁶ ions/cm²
- Normal incidence

Analysis

- Reflectivity measurement
- Depth profiles by Auger Electron Spectroscopy (AES)
- Cross sectional image by Transmission Electron Microscope (TEM)

Loss of multilayers


Increase of inter diffusion / Mixing

- Surface measurement by Atomic Force Microscopy (AFM)


Increase of surface roughness

- Implanted Xe analysis by X-ray Photoelectron Spectroscopy (XPS)

Absorption by implanted Xe




10 Mo/Si bilayer
Si substrate mirror
 $\lambda=13.5$ nm




Ref: Noriaki Kandaka et al, Proceedings of SPIE Vol. 4343 (2001), 599


AES depth profiles of ion exposed samples




Reference



Ion energy 5 keV, Ion dose 2.8×10^{16} atoms/cm²







Reference
(10 Mo/Si bilayer
Si substrate mirror)

Ion energy 5 keV
Ion dose 2.8×10^{16} atoms/cm²


AFM scan image of multilayer surface





Reference Rms: 0.196 nm



Ion energy 5 keV, Ion dose 2.8×10^{16} atoms/cm²
Rms: 0.411 nm



Implanted Xe analysis by XPS




Ion energy 5 keV
Ion dose 2.8×10^{16} atoms/cm²


Xe atomic %: 0.7% peak
Total depth: 8 nm



Negligible absorption at 13.5 nm (<0.5%)



Monte-Carlo TRIM



Fitting parameters

Items	reference	2keV	3keV	5keV
Layer period (Å)	69.6	69.15	69.55	69.55
Number of pairs	10	8	7	5
Thickness ratio	0.35	0.35	0.35	0.35
Interface layer thickness (Å)	17.9	17.9	17.9	17.9
Interface roughness (Årms)	1.2	3.7	4.1	3.6

Ref: Noriaki Kandaka et al, Proceedings of SPIE Vol. 4343 (2001), 599



Clarify the damage mechanism of collector mirror by Xe ion exposure test with ion gun

- Ion sputtering of multilayer is the main mechanism.
- Multilayer boundary mixing and surface roughness increase is also observed.
- EUV absorption by implanted Xe is negligible.

Ion mitigation technology development

- Stop ions with buffer gas
- Magnetic field ion guide

Xe @ armor radius=50mm



Ions from laser produced plasma are characterized by time-of-flight measurement (TOF)

- Xe²⁺ is the main observed charge state.
- Up to Xe⁶⁺ ions are observed with 8-ns laser.
- Higher charge state Xe ions are observed with 150-ps laser.

Ion damage mechanism of the collector mirror has been clarified

- Multilayer sputtering by Xe ion is the main mechanism.
- Boundary mixing at surface bilayer and surface roughness increase is observed.
- EUV absorption by implanted Xe is negligible.

Ion mitigation technology development

Different schemes under investigation, e.g. Magnetic field ion guide

This work was performed under the management of
Extreme Ultraviolet Lithography System Development Association



a research and development program of

NEDO / METI.

Authors would also like to thank Noriaki Kandaka (Nikon Corporation) for the reflectivity measurement of the samples.